



Part Number Cross Reference Guide

This list designates direct replacement parts. Locate the Current Part Number in the Current Part column.
The part number in the old part number column is a direct replacement part..

Current Part Nos. 000000021 through 20-0614-3

Current Part	Old Part	Current Part	Old Part	Current Part	Old Part
000000021	82-5025-3	13-6096-1	13-6096-3	15-0273-1	85-0331-3
000000022	20-0388-3	13-6122-1	83-7207-3	20-0000-3	23-5535-3
000000028	85-0438-3	13-6703-1	13-6118-1	20-0000-3	23-5535-9
000000112	602355-1	13-6703-1	13-6119-1	20-0018-9	24-1315-3
000000150	602981-4	13-7302-1	13-7301-1	20-0018-9	20-0018-3
000000558	000000217	13-7305-9	13-7305-1	20-0024-9	24-0024-3
000000588	20-0202-3	13-7601-9	13-7601-1	20-0030-3	20-0660-9
000001507	88-6535-3	14-8027-9	14-8027-1	20-0058-3	24-1318-3
000001508	88-6518-7	14-8027-9	14-8039-9	20-0081-3	25-1119-3
000001508	88-6536-3	14-8027-9	84-8056-3	20-0096-3	20-0028-3
000001508	88-6537-3	14-8027-9	84-8072-3	20-0116-3	24-1031-3
10604-1	10232-1	14-8027-9	84-8081-3	20-0124-3	23-5541-3
10699-1	44-0763-1	14-8027-9	84-8087-3	20-0124-3	23-5543-3
10992-1	15041-1	15010-1	681961-4	20-0126-3	20-0000-3
11-5021-1	11-5016-1	15088-1	10540-1	20-0126-3	23-5535-9
11-5023-1	11-5014-1	15177-1	44-0779-1	20-0126-3	23-5539-3
11-6509-7	11-6509-1	15538-9	15538-1	20-0126-3	20-0127-3
11-6511-7	11-6511-1	15543-9	15543-1	20-0127-3	23-5539-3
12558-1	10228-1	15544-9	15544-1	20-0129-3	20-0067-3
12558-1	10229-1	15545-9	15545-1	20-0133-3	85-0352-3
12596-9	12596-1	15552-1	11841-1	20-0116-9	20-0116-3
12674-1	12521-1	15553-9	15553-1	20-0126-3	20-0000-3
12709-9	12709-1	15592-2	15592-1	20-0141-3	84-8084-3
12938-2	12938-1	15628-3	15180-1	20-0142-3	84-8089-3
12970-9	12970-1	15628-3	603031-4	20-0154-3	24-1028-3
12-0022-1	12-0018-1	15-0001-1	85-0323-3	20-0182-3	20-3328-3
12-3005-9	89-3017-3	15-0002-1	85-0324-3	20-0183-3	20-0062-3
12-6003-3	12-6001-1	15-0003-1	15-0254-1	20-0205-3	20-0791-9
12-6003-3	13-6067-1	15-0003-1	85-0325-3	20-0222-9	23-5546-3
13037-2	12856-1	15-0237-1	15-0271-1	20-0222-9	20-0620-3
13-0005-9	13-0005-1	15-0259-9	15-0259-1	20-0571-3	82-5065-3
13-0049-1	13-0042-1	15-0261-9	15-0261-1	20-0572-3	82-5063-3
13-3014-9	13-3014-1	15-0268-1	85-0329-3	20-0614-3	25-1125-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
20-0656-9	20-0153-3
20-0657-9	20-0154-3
20-0660-9	20-0030-3
20-0660-9	20-1035-9
20-0661-9	20-0116-9
20-0751-9	85-0487-3
20-0752-9	85-0558-3
20-0753-9	85-0483-3
20-0754-9	85-0433-3
20-0755-9	85-0457-3
20-0756-9	20-0003-3
20-0757-9	85-0497-3
20-1013-3	85-0432-3
20-1014-3	85-0366-3
20-3105-9	20-3105-3
20-3105-9	20-3187-3
20-3146-3	20-3075-3
20-3166-3	20-3123-3
20-3185-3	20-3126-3
20-3298-3	20-3273-3
20-3305-3	20-3274-3
20-7311-3	20-7687-3
20-7810-3	20-7720-3
22-0208-3	22-0003-1
22-0229-9	22-0229-3
23-0079-9	23-0074-1
23-0079-9	23-0079-1
23-0084-9	23-0056-1
23-0084-9	23-0084-1
23-0084-9	23-0117-3
23-0106-3	23-0067-1
23-0111-9	23-0111-3
23-0111-9	620641-4
23-0111-9	626341-4
23-0112-3	23-5515-3
23-0116-9	23-0116-3
23-0116-9	23-0122-3
23-0124-3	23-5520-3
23-0139-3	23-0132-3

Current Part	Old Part
23-0139-3	23-0133-3
23-0140-9	23-0140-3
23-0148-3	23-0144-3
23-0148-3	23-0145-3
23-0148-3	23-0147-3
23-0148-3	76-2506-3
23-5089-1	23-5081-1
23-5089-1	23-5502-1
23-5100-3	23-5082-1
23-5100-3	23-5084-1
23-5100-3	23-5086-1
23-5101-3	23-5092-1
23-5102-3	23-5002-1
23-5102-3	23-5094-3
23-5103-3	23-5088-1
23-5103-3	23-5093-1
23-5103-3	23-5096-3
23-5105-3	23-5079-1
23-5105-3	23-5506-1
23-5107-9	23-5107-3
23-5107-9	23-5122-3
23-5107-9	23-5128-3
23-5107-9	23-5128-9
23-5107-9	23-5129-3
23-5107-9	23-5130-3
23-5501-1	23-5078-1
23-5517-9	23-5517-3
23-5519-3	23-5509-1
23-5519-3	23-5510-3
23-5524-3	23-5534-3
23-5531-9	23-5531-3
23-5533-9	23-5533-3
23-5536-9	23-5536-3
23-5540-9	23-5532-3
23-5540-9	23-5532-9
23-5540-9	23-5540-3
24-0000-3	20-0009-3
24-0001-3	20-0010-3
24-0221-1	24-1232-3

Current Part	Old Part
24-0407-1	24-0409-1
24-0407-1	24-0413-1
24-0424-3	24-0404-1
24-0424-3	24-0431-3
24-0424-3	24-0454-3
24-0437-3	24-0218-1
24-0437-3	24-0410-1
24-0437-3	24-0419-3
24-0437-3	24-0421-3
24-0448-3	24-0435-3
24-0520-3	24-0461-9
24-0520-3	24-0462-9
24-0520-3	24-0489-3
24-0520-3	24-0490-3
24-0520-3	24-0492-3
24-0521-3	24-0489-3
24-0530-3	24-0524-3
24-0531-3	24-0514-3
24-0543-3	76-3005-1
24-0623-9	24-0608-1
24-0623-9	24-0611-1
24-0623-9	24-0612-1
24-0623-9	24-0616-1
24-0623-9	24-0622-3
24-0623-9	24-0626-3
24-0623-9	24-0634-3
24-0635-3	24-0629-3
24-0642-3	24-0636-3
24-0642-3	24-0637-3
24-0642-3	70064-3
24-0642-3	70065-3
24-0643-3	24-0641-3
24-0816-3	24-0817-3
24-0822-3	24-0818-3
24-1016-9	24-1016-3
24-1035-3	24-1033-3
24-1215-3	24-1228-3
24-1219-3	24-1203-1
24-1219-3	24-1212-1

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
24-1237-3	24-0159-1
24-1281-3	24-1280-3
24-1282-3	24-1286-3
24-1287-3	24-1251-3
24-1288-3	24-1233-3
24-1288-3	24-1259-3
24-1292-9	24-1264-3
24-1292-9	24-1264-9
24-1292-9	24-1292-3
24-1293-9	24-1278-3
24-1293-9	24-1278-9
24-1293-9	24-1293-3
24-1300-3	24-1263-3
24-1300-3	24-1269-3
24-1300-3	24-1276-3
24-1301-3	24-1279-3
24-1308-9	24-1308-3
24-1309-9	24-1309-3
24-1602-1	24-1614-3
24-1608-9	24-1608-3
24-1611-3	24-1623-3
24-1612-3	24-1623-3
24-1612-3	24-1611-3
25-0001-9	25-0001-1
25-0002-9	25-0002-1
25-0007-9	25-0007-1
25-0010-9	25-0010-1
25-0011-9	25-0011-3
25-0013-9	25-0013-3
25-0016-9	25-0016-3
25-0140-9	25-0140-1
25-0205-9	25-0205-3
25-0207-3	25-0211-3
25-0208-9	25-0208-3
25-0218-9	25-0218-3
25-1034-9	25-1034-3
25-1037-9	25-1037-3
25-1116-9	25-1116-3
25-1119-3	25-1085-3

Current Part	Old Part
25-1119-3	25-1107-3
25-1137-3	25-1150-3
25-1147-3	25-1145-3
29-0030-3	29-0028-3
29-0222-9	29-0222-3
29-0222-9	23-5546-3
30245-2	30245-1
30-1005-1	11834-1
30-1022-9	30-1022-3
30-1025-3	33-0020-3
30-1027-9	30-1027-3
30-1506-9	30-1501-1
30-1506-9	30-1506-1
30-1507-9	30-1507-1
30-6026-3	30-6009-1
30-6032-3	30-6029-3
33-0252-9	33-0252-3
33-0260-3	33-0255-3
34-0605-1	34-0061-1
34-5011-9	34-5011-3
37-0407-3	37-0404-1
37-0407-3	37-0409-3
37-1202-9	37-1202-1
37-1203-1	37-1207-3
37-1204-9	37-1204-3
37-1210-9	37-1210-3
37-1402-3	37-1401-3
37-1819-9	37-1819-3
37-3005-9	37-3005-3
37-3006-9	37-3006-3
37-3010-9	37-3010-3
37-3016-9	37-3016-3
40-0012-9	40-0012-3
40-0473-3	602707-1
40-0474-3	602958-1
40-0475-3	601399-1
40-0478-3	600750-1
40-0479-3	600750-1
40-0479-3	603767-1

Current Part	Old Part
40-0479-3	76-0123-3
40-0523-3	605092-1
40-0851-3	600244-1
40-0863-3	602850-1
40-0911-3	76-0124-3
40-0944-3	604716-1
40-1205-3	44-2138-3
40-4023-3	42-4023-3
43-0004-9	43-0004-1
43-0045-9	43-0045-3
43-0052-9	43-0052-3
43-0062-9	43-0062-3
43-0091-9	43-0091-1
43-0139-9	43-0139-3
43-0140-9	43-0140-3
43-0155-9	43-0155-3
43-0201-9	43-0201-3
43-0215-9	43-0215-3
43-0221-9	43-0221-3
43-0266-9	43-0266-3
43-0272-3	37-3020-3
43-0274-9	43-0274-3
43-0374-3	43-0354-3
43-0376-3	43-0372-3
43-0453-9	43-0453-3
43-0464-3	602855-1
44-0004-9	44-0004-3
44-0004-9	601531-4
44-0005-9	44-0005-3
44-0013-3	603558-1
44-0698-9	44-0698-1
44-0702-9	44-0702-3
44-0800-9	11468-1
44-0800-9	44-0800-3
44-0820-9	44-0138-1
44-0820-9	44-0139-3
44-0820-9	44-0139-9
44-0820-9	44-0820-3
44-0821-9	44-0752-1

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
44-0821-9	44-0752-9
44-0821-9	44-0821-3
44-2030-9	44-2030-1
44-2033-3	44-0757-1
44-2036-3	44-2014-1
44-2038-3	44-2064-3
44-2038-3	44-2067-3
44-2038-3	44-2103-3
44-2101-3	44-2090-3
44-2102-3	44-2089-3
44-2105-3	44-2082-3
48-0004-1	681951-4
50-0001-3	50-1204-9
50-0001-3	53-0510-3
50-0001-3	53-0511-3
50-0010-9	50-0010-3
50-0026-9	50-0026-3
50-0537-9	50-0506-9
50-1204-9	50-1204-1
50-1205-9	50-1205-1
50-1207-9	50-1207-3
50-1208-3	50-1206-3
50-1209-9	50-1209-3
50-1210-9	50-1210-3
50-1215-9	50-1215-3
50-1216-9	50-1216-3
50-1216-9	50-1236-3
50-1225-9	50-1225-3
50-1227-9	50-1222-3
50-1227-9	50-1222-9
50-1227-9	50-1227-3
50-1230-9	50-1230-3
50-1231-9	50-1231-3
50-1234-9	50-1234-3
50-1308-9	50-1308-1
50-1313-9	43-0181-3
50-1313-9	50-1313-3
50-1313-9	50-1322-3
50-1314-9	50-1314-3

Current Part	Old Part
50-1317-9	50-1317-3
50-1329-9	50-1329-3
50-1452-9	50-1452-3
50-2061-9	50-2061-1
50-2234-9	50-2234-1
50-2237-9	50-2237-1
50-2238-9	50-2238-3
50-2239-9	50-2239-3
50-2240-9	50-2240-3
50-2241-9	50-2241-3
50-2274-9	50-2274-1
50-2276-9	50-2276-1
50-2329-9	50-2326-1
50-2329-9	50-2326-9
50-2329-9	50-2329-1
50-2350-9	50-2350-3
50-2551-9	50-2551-1
50-2559-9	50-2559-3
50-2616-9	50-2616-1
50-2624-9	50-2624-1
50-2668-9	50-2667-1
50-2668-9	50-2667-9
50-2668-9	50-2668-3
50-2672-9	50-2672-1
50-2673-9	50-2673-1
50-2701-9	50-2701-1
50-2702-9	50-2702-1
50-2703-9	50-2703-3
50-2704-9	50-2704-3
50-2707-9	50-2707-3
50-2726-9	50-2726-3
50-2932-9	50-2932-3
50-3013-9	50-3013-1
50-3015-9	50-3012-1
50-3015-9	50-3012-9
50-3015-9	50-3015-3
50-3184-9	50-3184-1
50-3236-9	50-3236-1
50-3345-9	50-3345-1

Current Part	Old Part
50-3351-9	50-3351-3
50-3353-9	50-3353-3
50-3357-9	50-3357-3
50-3358-9	50-3238-3
50-3358-9	50-3238-9
50-3358-9	50-3358-3
50-3565-9	50-3565-1
50-3570-9	50-3570-3
50-3572-9	50-3572-3
50-3764-9	50-3764-1
50-3765-9	50-3765-1
50-3767-9	50-3767-3
50-3770-9	50-3770-3
51-1901-9	51-1901-3
51-1902-9	51-1902-3
51-2153-9	51-2153-1
51-2155-9	51-2155-3
51-2158-9	51-2158-3
51-2162-9	51-2162-3
51-2164-9	51-2164-3
51-2166-9	51-2166-3
51-2167-9	51-2167-3
51-2464-9	51-2154-1
51-2464-9	51-2154-9
51-2464-9	51-2464-1
51-2464-9	52-0103-3
51-2464-9	52-0103-9
51-2465-9	51-2465-1
51-3472-9	51-3472-1
52-0205-9	52-0205-3
52-0206-9	52-0206-3
52-0207-9	52-0207-3
52-0208-9	52-0208-3
52-0209-9	51-2159-3
52-0209-9	52-0209-3
52-0210-9	52-0210-3
52-0212-9	52-0212-3
52-0215-9	52-0215-3
52-0216-9	52-0216-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
52-0217-9	52-0217-3
52-0218-9	52-0218-3
52-0223-9	52-0223-3
52-0301-9	52-0301-3
53-0504-9	53-0504-3
53-0509-9	53-0509-3
53-0511-3	53-0510-3
54-2853-9	54-2853-3
54-2878-9	54-2878-1
54-2906-9	54-2906-1
54-2910-9	54-2910-3
54-2912-9	54-2912-3
54-2929-9	54-2929-1
54-2943-9	54-2943-1
54-2945-9	54-2945-1
54-2952-9	54-2952-1
54-2953-9	54-2953-1
54-2955-9	54-2955-3
54-2956-9	54-2956-3
54-2975-9	54-2975-1
54-3002-9	54-3002-1
54-3002-9	54-3003-1
54-3002-9	54-3003-9
54-3052-9	54-3052-1
54-7303-9	54-7303-3
54-7304-9	54-7304-3
54-7501-9	54-7501-1
54-7503-9	54-7503-3
54-7504-9	54-7504-3
54-7507-9	54-7507-3
54-8904-9	54-8904-1
54-8906-9	54-8906-3
54-8908-9	54-8908-3
54-8909-9	54-8909-3
54-8911-9	54-8911-3
54-8913-9	54-8902-1
54-8913-9	54-8902-9
54-8913-9	54-8913-3
55-0408-9	55-0408-1

Current Part	Old Part
55-0408-9	55-0476-1
55-0408-9	55-0476-9
55-0426-9	55-0426-1
55-0427-9	55-0427-1
55-0526-9	55-0526-3
55-4407-9	55-4407-1
55-4454-9	55-4454-1
55-4459-9	55-4459-1
55-4460-9	55-4460-1
55-4464-9	55-4464-1
55-4496-9	55-4496-1
55-4510-9	55-4510-1
55-4511-9	55-4511-1
55-4514-9	55-4514-1
55-4516-9	55-4516-3
55-4518-9	55-4518-1
55-7304-9	55-7304-1
55-7305-9	55-7305-1
55-7311-9	55-7311-1
55-7313-9	55-7313-1
55-7316-9	55-7316-3
55-7317-9	55-7317-3
55-7320-9	55-7320-3
55-7321-9	55-7321-3
55-7323-9	55-7323-3
55-7328-9	55-7328-3
55-7329-9	55-7329-3
55-7335-9	55-7335-3
55-7337-9	55-7337-3
55-7338-9	55-7338-3
55-7339-9	55-7339-3
55-7341-9	55-7341-3
56-1002-9	56-1002-3
56-1008-9	56-1008-3
56-1009-9	56-1009-3
56-1010-9	56-1010-3
56-1011-9	56-1011-3
56-4806-9	56-4806-3
56-4808-9	56-4808-3

Current Part	Old Part
56-4811-9	56-4811-3
56-4820-9	56-4820-3
56-4826-9	56-4826-3
56-4827-9	56-4827-3
56-4828-9	56-4828-3
56-5003-9	56-5003-1
56-5004-9	56-5004-1
56-5035-9	56-5035-1
56-5039-9	56-5039-3
56-5042-9	56-5042-3
56-5045-9	56-5045-3
56-5047-9	56-5036-1
56-5047-9	56-5047-3
56-5052-9	56-5052-3
56-5053-9	56-5053-3
56-5060-9	56-5060-3
56-5064-9	56-5046-3
56-5064-9	56-5046-9
56-5064-9	56-5064-3
56-5065-9	56-5065-3
56-5069-9	56-5069-3
56-5070-9	56-5070-3
56-5072-9	50-1323-3
56-5072-9	50-1323-9
56-5072-9	56-5072-3
56-5075-3	83-7302-3
56-5079-9	56-5079-3
56-5080-9	56-5080-3
56-5090-9	56-5090-3
57-6843-9	57-6843-1
57-6865-9	57-6865-3
57-6877-9	57-6877-3
600399-1	650327-1
600488-1	624171-4
600656-1	15691-1
600656-1	660461-4
600890-1	662631-4
601001-1	44-2059-3
601032-1	600554-1

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
601202-1	624281-4
601279-1	600544-1
601284-1	600105-1
601287-1	600062-1
601293-1	600543-1
601294-1	600683-1
601352-1	600237-1
601383-4	603041-4
601383-4	605531-4
601389-1	600550-1
601391-1	601044-1
601408-1	600930-1
601409-1	600933-1
601410-1	600367-1
601424-1	600158-1
601425-1	600200-1
601427-1	600353-1
601433-1	600167-1
601438-1	600942-1
601500-1	630621-4
601664-1	650228-1
601664-1	650450-1
601664-1	650554-1
601665-1	650199-1
601665-1	650453-1
601665-1	650555-1
601667-1	650406-1
601667-1	650557-1
601668-1	650407-1
601668-1	650558-1
601669-1	650496-1
601669-1	650559-1
601768-1	600890-1
601769-1	605782-4
601772-1	626371-4
601773-1	631431-4
601774-1	659951-4
601775-1	659961-4
601776-1	662991-4

Current Part	Old Part
601778-1	666581-4
601787-1	688741-4
601788-1	688751-4
601790-1	600622-1
601792-1	600893-1
601794-1	688801-4
601804-1	600557-1
601869-1	600567-1
601871-1	630871-4
602242-1	601543-1
602375-1	602363-1
602641-4	11460-1
602707-1	600262-1
602850-1	600371-1
602958-1	601400-1
602981-4	11108-1
602981-4	11442-1
602991-4	10892-1
603001-4	10893-1
603021-4	15054-1
603021-4	15065-1
603564-1	602332-1
603901-4	10841-1
603902-4	10841-2
603996-1	603517-1
603997-1	603518-1
604017-1	603477-1
604226-1	603709-1
604295-1	601889-1
604296-1	601890-1
604409-1	603994-1
604693-1	602683-1
604710-1	602945-1
604778-1	604034-1
605092-1	602707-1
605096-1	604034-1
605096-1	604778-1
605097-1	43-0345-3
605491-1	604540-1

Current Part	Old Part
605492-1	604541-1
605495-1	604233-1
605499-1	604418-1
605500-1	604419-1
605665-1	604829-1
605749-1	600281-1
605824-1	604827-1
605825-1	604828-1
605873-4	70005-1
606811-4	10732-1
606841-4	44-0762-1
606864-9	605636-9
606714-9	606714-1
607244-3	606714-3
607244-3	606715-3
607246-1	606186-9
608041-4	10009-1
608041-4	12766-1
608201-4	11951-1
608201-4	25-0190-1
608742-4	11931-2
609751-4	10605-1
610562-4	610561-4
614931-4	613031-4
617511-4	11906-1
617541-4	650271-4
620261-4	11843-1
620281-4	10704-1
620281-4	10996-1
620281-4	96-0603-3
620471-4	606222-4
622201-9	622201-4
622201-9	624571-4
624241-4	617841-4
624601-4	626361-4
624641-9	624641-4
625971-4	613401-4
625971-4	620221-4
625972-4	613402-4

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
625972-4	620222-4
626001-4	601561-4
626002-4	44-0791-3
626002-4	601562-4
626511-4	13-6005-3
626971-4	625441-4
628451-9	628261-4
628451-9	628451-4
629021-4	624091-4
650053-4	10748-1
650053-4	650051-4
650512-1	650088-1
650521-4	12664-1
650521-4	15219-1
650521-4	15320-1
650541-9	650541-4
650791-4	15376-1
650791-4	601081-4
652063-4	15186-1
652063-4	652061-4
652082-4	15736-1
652882-4	652881-4
653232-4	12879-1
653232-4	76-1916-3
653681-9	653681-4
654081-4	650681-4
654141-4	44-0797-3
654392-4	650761-4
654392-4	654391-4
654881-9	654881-4
655271-4	10820-1
655271-4	10821-1
655271-4	10837-1
655271-4	10838-1
655271-4	11221-1
655271-4	15144-1
655271-4	15239-1
655271-4	15240-1
655271-4	44-2005-1

Current Part	Old Part
655271-4	44-2007-1
655271-4	607251-4
655271-4	653721-4
655271-4	653731-4
655291-4	12701-1
655291-4	12917-1
656391-4	15386-1
656391-4	44-0690-1
656621-4	10216-1
656621-4	10217-1
656621-4	12541-1
656621-4	15014-1
656621-4	653711-4
656861-4	11122-1
656861-4	15187-1
656861-4	654611-4
657111-4	656371-4
657112-4	656372-4
657891-4	15176-1
657951-4	656021-4
658031-9	600370-1
658031-9	658031-4
658031-9	663391-4
658041-9	32-0343-3
658041-9	600369-1
658041-9	601349-1
658041-9	601402-1
658041-9	658041-4
658041-9	663381-4
658252-4	658251-4
658262-4	658261-4
658661-4	656001-4
658671-4	656011-4
658831-4	653702-4
659051-4	659052-4
659691-4	10384-1
659691-4	15327-1
660731-4	618381-4
660741-4	659621-4

Current Part	Old Part
660771-4	658571-4
660781-4	658441-4
661101-4	651431-4
663191-4	658791-4
663602-4	663601-4
664581-4	660031-4
665231-4	655551-4
665361-4	662741-4
665521-4	664011-4
665522-4	664012-4
665831-9	665831-4
665974-4	665973-4
666031-4	665281-4
666981-4	663581-4
666981-4	663582-4
666991-4	618651-4
666991-4	660901-4
666991-4	663591-4
666991-4	663592-4
680301-9	12767-1
680301-9	680301-4
680302-9	12767-2
680302-9	680302-4
680311-9	12973-1
680311-9	680311-4
680312-9	12973-2
680312-9	680312-4
680321-9	680321-4
680331-9	680331-4
680472-4	15558-1
680472-4	680471-4
681203-4	12764-1
681203-4	681201-4
681203-4	681202-4
681732-9	681732-4
681733-9	681733-4
681971-4	12625-1
682471-9	12686-1
682471-9	12794-1

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
682471-9	682471-4
682471-9	70024-1
682472-9	12685-1
682472-9	12735-1
682472-9	682472-4
682472-9	70023-1
682473-9	12972-1
682473-9	682473-4
682481-9	682481-4
682482-9	682482-4
682483-9	682483-4
682992-9	682992-4
683002-9	683002-4
684292-9	684291-4
684292-9	684291-9
684292-9	684292-4
684311-9	684311-4
684311-9	76-2165-3
684311-9	76-2165-9
684321-9	684321-4
684321-9	76-2163-3
684321-9	76-2163-9
684331-9	684331-4
684331-9	76-2164-3
684331-9	76-2164-9
684511-9	684511-4
684521-9	684521-4
684531-9	684531-4
685531-4	76-2086-3
685531-4	76-2087-3
685771-9	685771-4
685771-9	688851-4
685773-9	688853-4
686153-4	683923-4
686161-9	686161-4
686161-9	688841-4
686163-9	686163-4
686163-9	688843-4
686721-9	686721-4

Current Part	Old Part
686721-9	687651-4
687251-9	687251-4
687251-9	688831-4
687253-9	687253-4
687253-9	688833-4
687711-9	687711-4
687711-9	687851-4
687721-9	687721-4
687721-9	687861-4
687791-9	687791-4
687791-9	688031-4
70057-3	83-9010-3
70-0062-3	71-1173-3
71-0796-9	71-0727-9
71-0825-9	71-0751-9
71-0825-9	71-0835-9
71-0860-9	71-1127-3
71-0860-9	71-1193-3
71-0975-9	71-0975-3
71-0975-9	71-0976-3
71-1173-3	626021-4
76-0002-3	84-0240-3
76-0003-3	84-0241-3
76-0004-3	84-0242-3
76-0005-3	84-0237-3
76-0006-3	84-0249-3
76-0007-3	84-0250-3
76-0008-3	84-0243-3
76-0009-3	84-0244-3
76-0017-3	76-2913-3
76-0017-3	82-5039-3
76-0017-3	83-6773-3
76-0018-3	82-5038-3
76-0018-3	82-5044-3
76-0019-3	82-5095-3
76-0020-3	82-5031-3
76-0021-3	82-5037-3
76-0022-3	76-2692-3
76-0022-3	82-5036-3

Current Part	Old Part
76-0022-3	83-6774-3
76-0050-3	82-5066-3
76-0052-3	82-5035-3
76-0054-3	82-5013-3
76-0056-3	82-5004-3
76-0057-3	82-5020-3
76-0058-3	82-5021-3
76-0059-3	82-5012-3
76-0060-3	82-5018-3
76-0071-3	82-5050-3
76-0072-3	82-5052-3
76-0075-3	82-5062-3
76-0081-3	604531-1
76-0082-3	604532-1
76-0085-3	44-2139-3
76-0086-3	44-2143-3
76-0105-3	76-0103-3
76-0112-3	24-0515-3
76-0112-3	24-0516-3
76-0112-3	24-0526-3
76-0112-3	24-0527-3
76-0112-3	24-0528-3
76-0113-3	24-0529-3
76-0123-3	602855-1
76-0124-3	602855-1
76-0134-3	76-0107-3
76-0135-3	76-0108-3
76-0162-3	82-5224-3
76-0163-3	82-5225-3
76-0164-3	605562-1
76-0165-3	605695-1
76-0328-3	76-2821-3
76-0329-3	76-2822-3
76-0330-3	76-2823-3
76-1942-3	655321-4
76-1943-3	11571-1
76-1956-3	655371-4
76-1965-9	683471-4
76-1965-9	76-1965-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-1966-9	683472-4
76-1966-9	76-1966-3
76-1967-9	683481-4
76-1967-9	76-1967-3
76-1968-9	683482-4
76-1968-9	76-1968-3
76-1969-9	683491-4
76-1969-9	76-1969-3
76-1970-9	683492-4
76-1970-9	76-1970-3
76-1976-3	15615-1
76-1984-3	24-1231-3
76-1985-3	24-1218-3
76-1985-3	24-1230-3
76-1986-3	656351-4
76-1987-3	659071-4
76-1989-3	684231-4
76-1992-3	76-2117-3
76-1992-3	76-2145-3
76-1993-3	76-2118-3
76-1996-3	25-1046-3
76-1996-3	25-1061-3
76-1997-3	76-2351-3
76-2007-3	683551-4
76-2008-3	684232-4
76-2013-3	22-0213-3
76-2013-3	22-0214-3
76-2018-3	24-1224-3
76-2018-3	76-2053-3
76-2019-3	24-1225-3
76-2027-3	84-0041-3
76-2027-3	84-0041-9
76-2027-3	84-0196-3
76-2028-3	14-0005-1
76-2028-3	14-0005-9
76-2028-3	84-0025-3
76-2028-3	84-0040-3
76-2028-3	84-0040-9
76-2028-3	84-0068-3

Current Part	Old Part
76-2028-3	84-0068-9
76-2028-3	84-0197-3
76-2036-3	14-0171-1
76-2036-3	84-0037-3
76-2036-3	84-0037-9
76-2036-3	84-0121-3
76-2039-3	659161-4
76-2043-3	14-0019-1
76-2043-3	14-0019-9
76-2043-3	84-0036-3
76-2043-3	84-0036-9
76-2044-3	14-0018-1
76-2044-3	84-0023-3
76-2044-3	84-0054-3
76-2044-3	84-0054-9
76-2051-3	10512-1
76-2051-3	620331-4
76-2051-3	620332-4
76-2058-3	661811-4
76-2061-3	25-1047-3
76-2061-3	25-1062-3
76-2061-3	25-1095-3
76-2062-3	83-6713-3
76-2062-3	83-6715-3
76-2062-3	83-6719-3
76-2067-3	89-0026-3
76-2067-3	89-0028-3
76-2067-3	89-0030-3
76-2068-3	626403-4
76-2068-3	660911-4
76-2069-3	14-0001-1
76-2069-3	14-0012-1
76-2069-3	76-2026-3
76-2069-3	84-0024-3
76-2069-3	84-0042-3
76-2069-3	84-0042-9
76-2069-3	84-0195-3
76-2071-9	76-2071-3
76-2071-9	76-2166-3

Current Part	Old Part
76-2071-9	76-2166-9
76-2072-9	76-2072-3
76-2072-9	76-2167-3
76-2072-9	76-2167-9
76-2073-9	76-2073-3
76-2073-9	76-2168-3
76-2073-9	76-2168-9
76-2074-3	15273-1
76-2075-9	76-2075-3
76-2076-9	76-2076-3
76-2092-3	89-0032-3
76-2092-3	89-0032-9
76-2094-3	89-0008-3
76-2096-9	76-2096-3
76-2097-9	76-2097-3
76-2098-9	76-2098-3
76-2099-9	76-2099-3
76-2100-9	76-2100-3
76-2101-9	76-2101-3
76-2109-3	76-2057-3
76-2109-3	83-6720-3
76-2119-3	688861-4
76-2120-3	688863-4
76-2126-3	44-2039-3
76-2133-3	84-0020-3
76-2133-3	84-0020-9
76-2134-3	14-0014-1
76-2135-3	14-0017-1
76-2135-3	14-0017-9
76-2136-3	84-0028-3
76-2136-3	84-0028-9
76-2136-3	84-0057-3
76-2136-3	84-0057-9
76-2137-3	84-0031-3
76-2137-3	84-0031-9
76-2137-3	84-0059-3
76-2137-3	84-0059-9
76-2138-3	84-0027-3
76-2139-3	84-0035-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2139-3	84-0035-9
76-2139-3	84-0058-3
76-2139-3	84-0058-9
76-2140-3	620271-4
76-2140-3	620681-4
76-2148-3	76-1995-3
76-2149-3	76-2116-3
76-2150-3	76-1991-3
76-2159-3	683883-4
76-2159-3	76-2024-3
76-2170-9	76-2170-3
76-2177-3	43-0152-3
76-2177-3	43-0153-3
76-2177-3	43-0195-3
76-2177-3	43-0196-3
76-2177-3	613751-4
76-2177-3	613752-4
76-2177-3	613761-4
76-2177-3	613762-4
76-2182-3	76-2190-3
76-2186-3	84-0033-3
76-2186-3	84-0033-9
76-2186-3	84-0049-3
76-2186-3	84-0049-9
76-2191-3	44-2042-3
76-2192-3	24-0815-3
76-2192-3	24-1014-3
76-2195-3	662171-4
76-2199-3	76-1982-3
76-2202-3	83-6726-3
76-2202-3	83-6746-3
76-2202-3	83-6746-9
76-2207-3	56-5062-3
76-2208-9	687921-4
76-2208-9	76-2208-3
76-2209-9	687922-4
76-2209-9	76-2209-3
76-2210-9	687931-4
76-2210-9	76-2210-3

Current Part	Old Part
76-2211-9	687932-4
76-2211-9	76-2211-3
76-2212-9	687941-4
76-2212-9	76-2212-3
76-2213-9	687942-4
76-2213-9	76-2213-3
76-2214-3	76-2244-3
76-2228-3	624361-4
76-2237-3	70060-3
76-2237-3	70061-3
76-2240-9	76-2240-3
76-2241-9	76-2241-3
76-2242-9	76-2242-3
76-2243-9	76-2243-3
76-2251-3	83-6734-3
76-2255-3	70058-3
76-2261-3	76-2260-3
76-2267-3	83-6724-3
76-2273-3	658771-4
76-2283-3	627171-4
76-2306-3	14-8023-1
76-2306-3	14-8030-9
76-2306-3	84-8044-3
76-2306-3	84-8044-9
76-2306-3	84-8052-3
76-2306-3	84-8053-3
76-2306-3	84-8062-3
76-2306-3	84-8065-3
76-2306-3	84-8074-3
76-2306-3	84-8076-3
76-2306-3	84-8085-3
76-2306-3	84-8092-3
76-2306-3	84-8096-3
76-2306-3	84-8100-3
76-2307-3	76-2183-3
76-2308-3	76-2185-3
76-2326-3	76-2121-3
76-2326-3	89-0033-3
76-2326-3	89-0038-3

Current Part	Old Part
76-2326-3	89-0046-3
76-2327-3	89-0034-3
76-2327-3	89-0037-3
76-2329-3	30-0062-3
76-2329-3	34-0613-3
76-2329-3	601591-4
76-2331-3	630401-4
76-2332-3	85-0353-3
76-2335-3	24-1024-3
76-2337-3	37-0530-3
76-2337-3	37-2016-3
76-2337-3	37-3014-3
76-2349-3	624261-4
76-2350-3	624271-4
76-2352-3	76-2353-3
76-2354-3	76-2355-3
76-2356-3	76-2006-3
76-2358-3	76-2004-3
76-2369-3	84-0070-3
76-2369-3	84-0070-9
76-2375-3	25-1040-3
76-2375-3	25-1059-3
76-2375-3	25-1069-3
76-2376-3	25-1039-3
76-2376-3	25-1058-3
76-2376-3	25-1068-3
76-2380-3	34-0644-3
76-2380-3	34-0645-3
76-2380-3	34-0646-3
76-2380-3	34-0647-3
76-2381-3	34-0642-3
76-2381-3	34-0643-3
76-2381-3	34-0648-3
76-2381-3	34-0649-3
76-2383-3	24-1239-3
76-2385-3	84-0074-3
76-2392-3	84-0075-3
76-2392-3	84-0075-9
76-2396-3	25-1073-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2396-3	25-1080-3
76-2398-3	83-6721-3
76-2398-3	83-6739-3
76-2398-3	83-6747-3
76-2398-3	83-6747-9
76-2411-3	83-6735-3
76-2412-3	84-0085-3
76-2413-3	83-6737-3
76-2414-3	631781-4
76-2432-3	37-1046-3
76-2432-3	37-1046-9
76-2433-3	84-0089-3
76-2435-3	12576-1
76-2435-3	12576-9
76-2435-3	45-0002-3
76-2436-3	45-0003-3
76-2436-3	682411-4
76-2436-3	682411-9
76-2437-3	45-0004-3
76-2437-3	688331-4
76-2437-3	688331-9
76-2440-3	84-0099-3
76-2441-3	30-1001-1
76-2441-3	30-1002-1
76-2441-3	34-0670-3
76-2441-3	34-0671-3
76-2441-3	632571-1
76-2441-3	632572-1
76-2442-3	30-1014-3
76-2443-3	30-1015-3
76-2444-3	84-0090-3
76-2444-3	84-0100-3
76-2445-3	45-0001-3
76-2449-3	12799-1
76-2449-3	12799-9
76-2449-3	45-0006-3
76-2450-3	45-0005-3
76-2450-3	657621-4
76-2450-3	657621-9

Current Part	Old Part
76-2450-3	685591-4
76-2451-3	600007-1
76-2452-3	665981-4
76-2453-3	664021-4
76-2457-3	687231-4
76-2458-3	685391-4
76-2464-3	83-6758-3
76-2465-3	83-6740-3
76-2471-9	76-2471-3
76-2472-9	76-2472-3
76-2473-9	76-2473-3
76-2476-3	45-0007-3
76-2498-3	43-0228-3
76-2498-3	43-0229-3
76-2498-3	43-0327-3
76-2498-3	43-0452-3
76-2501-9	76-2501-3
76-2502-9	76-2502-3
76-2503-9	76-2503-3
76-2507-3	600059-1
76-2507-3	601288-1
76-2508-3	76-2516-3
76-2508-3	76-2740-3
76-2508-3	76-2741-3
76-2508-3	83-6759-3
76-2508-3	83-6769-3
76-2510-9	76-2510-3
76-2511-9	76-2511-3
76-2512-9	76-2512-3
76-2513-9	76-2468-3
76-2513-9	76-2468-9
76-2513-9	76-2513-3
76-2514-9	76-2469-3
76-2514-9	76-2469-9
76-2514-9	76-2514-3
76-2515-9	76-2470-3
76-2515-9	76-2470-9
76-2515-9	76-2515-3
76-2517-3	84-0122-3

Current Part	Old Part
76-2518-9	76-2518-3
76-2519-9	76-2519-3
76-2520-9	76-2520-3
76-2523-3	600159-1
76-2525-3	76-2460-3
76-2526-3	76-2461-3
76-2535-3	83-6748-3
76-2535-3	83-6757-3
76-2539-3	601430-1
76-2541-3	84-0127-3
76-2547-3	683843-4
76-2547-3	683846-4
76-2547-3	685773-4
76-2547-3	685773-9
76-2547-3	76-2120-3
76-2552-3	84-8071-3
76-2552-3	84-8098-3
76-2552-3	84-8099-3
76-2554-3	650409-1
76-2556-3	76-2399-3
76-2556-3	83-6741-3
76-2557-3	76-2400-3
76-2557-3	83-6742-3
76-2558-3	76-2401-3
76-2558-3	83-6743-3
76-2566-3	83-6751-3
76-2566-3	83-6761-3
76-2567-3	600653-1
76-2583-3	83-6752-3
76-2583-3	83-6762-3
76-2584-9	76-2584-3
76-2585-9	76-2585-3
76-2586-9	76-2586-3
76-2587-9	76-2587-3
76-2590-3	84-0143-3
76-2601-3	14-8031-1
76-2601-3	14-8031-9
76-2601-3	76-2268-3
76-2601-3	76-2269-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2601-3	84-8040-3
76-2601-3	84-8040-9
76-2601-3	84-8041-3
76-2601-3	84-8043-3
76-2601-3	84-8046-9
76-2601-3	84-8048-3
76-2601-3	84-8049-3
76-2601-3	84-8050-3
76-2601-3	84-8051-3
76-2601-3	84-8054-3
76-2601-3	84-8055-3
76-2601-3	84-8066-3
76-2601-3	84-8068-3
76-2601-3	84-8069-3
76-2601-3	84-8070-3
76-2601-3	84-8075-3
76-2601-3	84-8077-3
76-2601-3	84-8078-3
76-2601-3	84-8079-3
76-2601-3	84-8080-3
76-2601-3	84-8086-3
76-2601-3	84-8093-3
76-2601-3	84-8097-3
76-2603-3	84-0108-3
76-2610-3	85-0369-3
76-2610-3	85-0388-3
76-2611-3	85-0381-3
76-2613-3	23-5125-3
76-2616-3	601831-8
76-2617-3	84-0140-3
76-2619-3	84-0133-3
76-2620-3	84-0141-3
76-2624-3	601002-1
76-2635-3	84-0152-3
76-2636-3	84-0153-3
76-2637-3	84-0151-3
76-2638-3	24-1235-3
76-2638-3	24-1260-3
76-2647-3	76-2769-3

Current Part	Old Part
76-2648-3	600795-1
76-2648-3	601036-1
76-2650-3	76-2431-3
76-2657-9	76-2657-3
76-2658-9	76-2658-3
76-2664-3	601116-1
76-2669-3	76-2426-3
76-2670-3	76-2427-3
76-2671-3	76-2428-3
76-2672-3	20-0073-3
76-2672-3	24-1265-3
76-2672-3	24-1296-3
76-2673-3	20-0074-3
76-2673-3	24-1284-3
76-2673-3	24-1297-3
76-2674-3	76-2418-3
76-2674-3	76-2419-3
76-2674-3	76-2627-3
76-2674-3	76-2634-3
76-2674-3	84-0092-3
76-2674-3	84-0093-3
76-2674-3	84-0145-3
76-2674-3	84-0148-3
76-2674-3	84-0154-3
76-2676-3	76-2625-3
76-2676-3	76-2632-3
76-2676-3	84-0146-3
76-2676-3	84-0149-3
76-2676-3	84-0155-3
76-2679-3	601209-1
76-2681-3	24-1249-3
76-2681-3	76-2374-3
76-2681-3	76-2537-3
76-2681-3	76-2606-3
76-2683-3	24-1250-3
76-2685-3	24-1019-3
76-2685-3	24-1020-3
76-2685-3	24-1032-3
76-2685-3	76-2192-3

Current Part	Old Part
76-2686-3	44-0892-3
76-2686-3	600187-1
76-2686-3	600293-1
76-2686-3	600563-1
76-2686-3	600585-1
76-2686-3	600686-1
76-2686-3	600726-1
76-2686-3	600947-1
76-2687-3	84-0157-3
76-2687-3	84-0207-3
76-2687-3	84-0207-9
76-2688-3	84-0158-3
76-2688-3	84-0208-3
76-2689-3	84-0180-3
76-2690-3	84-0181-3
76-0022-3	83-6768-3
76-2693-9	76-2693-3
76-2694-9	76-2694-3
76-2695-9	76-2695-3
76-2696-9	76-2696-3
76-2697-9	76-2697-3
76-2698-9	76-2698-3
76-2700-3	84-0178-3
76-2700-3	84-0209-3
76-2701-3	84-0179-3
76-2701-3	84-0210-3
76-2702-3	84-0182-3
76-2703-3	84-0183-3
76-2704-3	601897-1
76-2705-3	83-6760-3
76-2706-3	83-6749-3
76-2707-3	76-2144-3
76-2707-3	83-6722-3
76-2707-3	83-6727-3
76-2707-3	83-6733-3
76-2707-3	83-6750-3
76-2707-3	83-6770-3
76-2711-3	84-0159-3
76-2712-3	84-0161-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2713-3	84-0160-3
76-2723-3	84-0166-3
76-2724-3	76-2608-3
76-2724-3	76-2630-3
76-2724-3	76-2728-3
76-2724-3	84-0130-3
76-2724-3	84-0134-3
76-2724-3	84-0171-3
76-2724-3	84-0174-3
76-2725-3	76-2598-3
76-2725-3	76-2631-3
76-2725-3	76-2729-3
76-2725-3	84-0118-3
76-2725-3	84-0132-3
76-2725-3	84-0173-3
76-2726-3	76-2609-3
76-2726-3	76-2628-3
76-2726-3	76-2730-3
76-2726-3	84-0131-3
76-2726-3	84-0136-3
76-2726-3	84-0172-3
76-2726-3	84-0175-3
76-2727-3	83-6765-3
76-2731-3	83-6766-3
76-2734-3	83-6767-3
76-2735-3	90-0317-3
76-2738-3	84-8047-9
76-2747-3	14-8036-1
76-2748-3	600240-1
76-2752-3	84-0184-3
76-2753-3	84-0186-3
76-2754-3	84-0185-3
76-2775-3	37-1841-3
76-2781-3	25-1133-3
76-2781-3	25-1141-3
76-2782-3	25-1122-3
76-2782-3	25-1123-3
76-2782-3	25-1130-3
76-2782-3	76-2742-3

Current Part	Old Part
76-2785-3	601508-1
76-2785-3	650229-1
76-2785-3	650565-1
76-2786-3	601509-1
76-2786-3	650200-1
76-2786-3	650566-1
76-2787-3	601510-1
76-2787-3	650282-1
76-2787-3	650567-1
76-2788-3	601525-1
76-2788-3	650215-1
76-2788-3	650568-1
76-2789-3	601526-1
76-2789-3	650187-1
76-2789-3	650569-1
76-2790-3	601527-1
76-2790-3	650278-1
76-2790-3	650570-1
76-2791-3	25-1136-3
76-2794-3	84-0198-3
76-2800-3	25-1081-3
76-2800-3	25-1082-3
76-2800-3	25-1084-3
76-2800-3	25-1098-3
76-2800-3	25-1099-3
76-2800-3	25-1113-3
76-2800-3	25-1114-3
76-2800-3	25-1115-3
76-2800-3	25-1117-3
76-2800-3	25-1118-3
76-2800-3	25-1135-3
76-2802-3	23-0152-3
76-2806-3	91-0102-3
76-2808-3	602845-1
76-2809-3	602846-1
76-2810-3	76-2390-3
76-2810-3	76-2509-3
76-2810-3	76-2766-3
76-2810-3	84-0077-3

Current Part	Old Part
76-2810-3	84-0077-9
76-2810-3	84-0116-3
76-2810-3	84-0116-9
76-2810-3	84-0189-3
76-2811-3	76-2410-3
76-2811-3	76-2540-3
76-2811-3	76-2768-3
76-2811-3	84-0084-3
76-2811-3	84-0126-3
76-2811-3	84-0191-3
76-2812-3	76-2434-3
76-2812-3	76-2548-3
76-2812-3	76-2767-3
76-2812-3	84-0088-3
76-2812-3	84-0137-3
76-2812-3	84-0190-3
76-2813-3	76-2152-3
76-2813-3	76-2466-3
76-2813-3	76-2763-3
76-2813-3	84-0046-3
76-2813-3	84-0046-9
76-2813-3	84-0056-3
76-2813-3	84-0056-9
76-2813-3	84-0091-3
76-2813-3	84-0115-3
76-2813-3	84-0187-3
76-2815-3	76-2161-3
76-2815-3	76-2467-3
76-2815-3	76-2744-3
76-2815-3	84-0048-3
76-2815-3	84-0048-9
76-2815-3	84-0067-3
76-2815-3	84-0067-9
76-2815-3	84-0096-3
76-2815-3	84-0123-3
76-2815-3	84-0168-3
76-2815-3	84-0201-3
76-2816-3	76-2180-3
76-2816-3	76-2536-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2816-3	76-2745-3
76-2816-3	84-0055-3
76-2816-3	84-0055-9
76-2816-3	84-0072-3
76-2816-3	84-0072-9
76-2816-3	84-0125-3
76-2816-3	84-0170-3
76-2816-3	84-0202-3
76-2817-3	76-2542-3
76-2817-3	76-2746-3
76-2817-3	84-0128-3
76-2817-3	84-0169-3
76-2817-3	84-0203-3
76-2818-3	76-2500-3
76-2818-3	76-2771-3
76-2818-3	84-0114-3
76-2818-3	84-0192-3
76-2818-3	84-0204-3
76-2819-3	76-2527-3
76-2819-3	76-2772-3
76-2819-3	84-0139-3
76-2819-3	84-0194-3
76-2819-3	84-0205-3
76-2820-3	76-2773-3
76-2820-3	84-0142-3
76-2820-3	84-0193-3
76-2820-3	84-0206-3
76-2821-3	76-2245-3
76-2821-3	84-0060-3
76-2821-3	84-0060-9
76-2821-3	84-0221-3
76-2822-3	76-2246-3
76-2822-3	84-0061-3
76-2822-3	84-0061-9
76-2822-3	84-0222-3
76-2823-3	76-2262-3
76-2823-3	84-0062-3
76-2823-3	84-0062-9
76-2823-3	84-0223-3

Current Part	Old Part
76-2824-3	76-2263-3
76-2824-3	76-2561-3
76-2824-3	84-0063-3
76-2824-3	84-0063-9
76-2824-3	84-0144-3
76-2824-3	84-0224-3
76-2825-3	76-2215-3
76-2825-3	76-2562-3
76-2825-3	84-0051-3
76-2825-3	84-0051-9
76-2825-3	84-0069-3
76-2825-3	84-0069-9
76-2825-3	84-0129-3
76-2826-3	76-2216-3
76-2826-3	76-2565-3
76-2826-3	84-0052-3
76-2826-3	84-0052-9
76-2826-3	84-0138-3
76-2827-3	76-2264-3
76-2827-3	84-0064-3
76-2827-3	84-0064-9
76-2828-3	76-2265-3
76-2828-3	84-0065-3
76-2828-3	84-0065-9
76-2830-3	602871-1
76-2831-3	602870-1
76-2833-3	602840-1
76-2834-3	602839-1
76-2836-3	43-0394-3
76-2837-3	43-0291-3
76-2838-3	43-0317-3
76-2841-3	43-0364-3
76-2842-3	43-0310-3
76-2843-3	43-0318-3
76-2844-3	43-0350-3
76-2845-3	43-0319-3
76-2848-3	43-0365-3
76-2849-3	43-0312-3
76-2850-3	43-0321-3

Current Part	Old Part
76-2852-3	43-0385-3
76-2855-3	666471-4
76-2856-3	43-0288-3
76-2859-3	602706-1
76-2860-3	602705-1
76-2861-9	76-2861-3
76-2862-9	76-2862-3
76-2863-9	76-2863-3
76-2868-9	76-2868-3
76-2899-3	30-1038-3
76-2899-3	30-1043-3
76-2899-3	76-2846-3
76-2901-3	84-0233-3
76-2902-3	30-1040-3
76-2902-3	30-1044-3
76-2902-3	76-2839-3
76-2907-3	25-1139-3
76-2910-3	84-0217-3
76-2911-3	84-0218-3
76-2912-3	84-0219-3
76-2918-3	84-0229-3
76-2919-3	84-0227-3
76-2929-3	603224-1
76-2930-3	603225-1
76-2932-3	84-0200-3
76-2933-3	84-0199-3
76-2935-3	602639-1
76-2935-3	602640-1
76-2935-3	603130-1
76-2935-3	603164-1
76-2936-3	84-0230-3
76-2937-3	84-0231-3
76-2938-3	84-0232-3
76-2941-3	24-1257-3
76-2941-3	24-1294-3
76-2941-3	24-1313-3
76-2942-3	24-1295-3
76-2942-3	24-1314-3
76-2945-3	603544-1

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
76-2946-3	603542-1
76-2946-3	603543-1
76-2946-3	76-2949-3
76-2950-3	83-6777-3
76-2954-9	76-2954-3
76-2955-9	76-2955-3
76-2956-9	76-2956-3
76-2957-3	89-0047-3
76-2957-3	89-0049-3
76-2957-3	89-0054-3
76-2958-3	76-2326-3
76-2958-3	89-0048-3
76-2958-3	89-0050-3
76-2958-3	89-0055-3
76-2959-3	89-0002-3
76-2959-3	89-0051-3
76-2959-3	89-0056-3
76-2960-3	89-0053-3
76-2960-3	89-0057-3
76-2961-3	24-1312-3
76-2961-3	24-1317-3
76-2962-3	24-1311-3
76-2962-3	24-1316-3
76-2963-3	24-0540-3
76-2964-3	24-0541-3
76-2966-1	23-5126-3
76-3000-1	24-0499-3
76-3001-1	24-0496-3
76-3002-1	24-0456-3
76-3002-1	76-2113-3
76-3002-1	82-5134-3
76-3005-1	24-0525-3
76-3005-1	24-0537-3
76-3005-1	24-0543-3
76-3006-1	24-0500-3
76-3007-1	24-0505-3
76-3008-1	24-0457-3
76-3008-1	76-2114-3
76-3010-1	24-0455-3

Current Part	Old Part
76-3010-1	24-0503-3
76-3011-1	24-0495-3
76-3011-1	24-0504-3
76-3011-1	24-0536-3
89-0008-3	76-2094-3
81-0268-9	81-0268-1
81-3088-3	81-3092-3
81-3104-3	81-0364-1
81-3132-3	45-4151-3
81-3133-3	45-4140-1
81-3134-3	45-4136-1
81-3134-3	45-4160-3
81-3137-3	45-4163-3
81-3137-3	81-3158-3
81-3147-3	81-3121-3
81-3150-3	45-4141-1
81-3151-3	45-4143-3
81-3486-3	81-3134-3
81-3486-3	81-3135-3
81-3486-3	81-3424-3
81-3487-3	81-3136-3
81-3487-3	81-3140-3
81-3487-3	81-3175-3
81-3487-3	81-3452-3
81-3604-3	81-3032-1
82-5053-3	82-5030-3
82-5053-9	82-5053-3
82-5054-3	82-5026-3
82-5054-9	82-5054-3
82-5055-3	82-5027-3
82-5055-9	82-5055-3
82-5097-9	83-1017-3
82-5102-3	85-0409-3
82-5108-3	82-5107-3
82-5114-3	88-5126-3
82-5115-3	88-5127-3
82-5315-3	83-7206-7
83-5256-3	82-5014-3
83-6012-9	83-6012-3

Current Part	Old Part
83-6013-9	83-6013-3
83-6022-9	83-6022-3
83-6023-9	83-6023-3
83-6026-3	76-2056-3
83-6034-3	83-6003-3
83-6035-3	83-6004-3
83-6036-3	83-6021-3
83-6037-3	83-6016-3
83-6046-3	83-6137-3
83-6710-9	616001-4
83-6710-9	83-6710-3
83-6714-9	13-6706-1
83-6714-9	83-6708-3
83-6714-9	83-6709-3
83-6714-9	83-6714-3
83-6714-9	83-6716-3
83-6717-9	13-6707-1
83-6717-9	83-6717-3
83-6728-9	83-6728-3
83-6755-9	83-6755-3
83-6756-3	83-6725-3
83-6804-9	13-6801-1
83-6804-9	83-6802-3
83-6804-9	83-6803-3
83-6804-9	83-6804-3
83-6806-9	83-6806-3
83-6806-9	83-6807-3
83-6810-3	82-5116-3
83-6904-9	13-6902-1
83-6904-9	83-6904-3
83-6905-9	83-6905-3
83-6906-9	83-6906-3
83-6908-9	83-6908-3
83-7203-3	13-7201-1
83-7203-3	13-7202-1
83-7205-9	83-7205-3
83-7206-9	82-5282-9
83-7206-9	83-7206-3
83-7310-9	83-7310-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
83-7310-9	83-7319-3
83-7310-9	83-7320-3
83-7310-9	83-7321-3
83-7310-9	83-7322-3
83-7310-9	83-7323-3
83-7314-9	83-7314-3
83-7315-9	83-7315-3
83-7316-3	83-7329-3
83-7316-9	82-5023-3
83-7316-9	83-7316-3
83-7708-3	13-7703-1
83-7709-3	15-0262-1
83-8007-9	83-8007-3
85-0300-3	15-0272-1
85-0306-9	15-0260-1
85-0306-9	85-0306-3
85-0314-3	85-0304-3
85-0316-3	15-0285-1
85-0336-3	85-0318-3
85-0341-3	15-0238-1
85-0342-3	85-0339-3
85-0343-3	85-0340-3
85-0345-3	85-0302-3
85-0345-3	85-0315-3
85-0367-3	15-0235-1
85-0385-3	85-0377-3
85-0394-9	15-0258-1
85-0394-9	85-0394-3
85-0401-3	85-0303-3
85-0412-3	85-0462-3
85-0422-3	15-0237-1
85-0438-3	85-0434-3
85-0439-3	85-0345-3
85-0467-3	85-0452-3
85-0479-3	85-0468-3
85-0484-9	85-0484-3
85-0485-9	85-0485-3
85-0497-3	85-0378-3
85-0498-3	85-0368-3

Current Part	Old Part
85-0550-3	85-0569-3
85-0567-3	85-0515-3
85-0568-3	85-0570-3
85-0580-3	85-8580-3
87-0604-9	87-0604-3
87-0609-3	600242-1
88-0075-3	88-0076-3
88-0077-3	88-0073-3
88-5046-3	88-5040-3
88-5062-9	88-5032-3
88-5062-9	88-5034-3
88-5062-9	88-5062-3
88-5063-9	88-5033-3
88-5063-9	88-5042-3
88-5063-9	88-5063-3
88-5089-9	88-5045-3
88-5089-9	88-5089-3
88-5122-3	88-5091-3
88-5123-3	88-5098-3
88-6512-7	88-6512-3
88-6516-7	88-6516-3
88-6518-7	88-6518-3
88-6522-7	88-6522-3
88-6525-3	88-6521-3
88-6525-3	88-6521-7
88-6531-3	88-6519-3
88-6531-3	88-6519-7
88-6532-3	88-6517-3
88-6532-3	88-6517-7
88-6533-3	11-6510-1
88-6533-3	11-6510-7
88-6533-3	88-0533-3
88-6533-3	88-6515-3
88-6533-3	88-6515-7
88-6533-3	88-6530-3
88-6534-3	88-6527-3
88-6535-3	88-6529-3
88-6536-3	88-6520-3
88-6536-3	88-6520-7

Current Part	Old Part
88-6537-3	88-6525-3
89-0008-3	89-0005-3
89-0008-3	89-0006-3
89-0009-3	89-0007-3
89-3022-9	12-3005-1
89-3022-9	12-3005-9
89-3022-9	12-3006-1
89-3022-9	89-3020-3
89-3022-9	89-3022-3
89-3024-9	89-3024-3
89-3025-3	89-3023-3
89-3025-9	89-3022-9
89-3025-9	89-3025-3
89-3026-3	12-3009-1
89-3026-3	89-3010-3
89-3026-3	89-3010-9
89-3026-3	89-3012-3
89-3026-3	89-3014-3
89-3026-3	89-3015-3
89-3027-3	89-3016-3
89-3027-3	89-3021-3
89-3027-9	89-3026-3
89-3027-9	89-3027-3
89-5007-3	651341-4
89-5007-3	651342-4
91-0069-1	91-0072-1
92-0212-9	92-0212-1
92-0248-9	92-0214-1
92-0248-9	92-0214-9
92-0248-9	92-0248-3
92-0250-9	92-0213-1
92-0250-9	92-0213-9
92-0250-9	92-0235-3
92-0250-9	92-0235-9
92-0250-9	92-0250-3
95-0025-9	95-0025-3
97-5002-3	34-0688-3
97-5027-9	97-5027-3
97-5065-9	97-5065-3

Current Parts are indicated on Parts Manual Pages by the † symbol.

Current Part	Old Part
97-5075-3	97-5073-3
97-5093-3	97-5062-3
202-FN-1101	13-7601-9

